


# DIAGRAM OF MODEL NO BEX 90/40LV



## PARTS LIST FOR 90/40LW

\*When ordering spare parts, please state item no., part no. and description.

ITEM NO.	PART NO.	DESCRIPTION	ITEM NO.	PART NO.	DESCRIPTION	ITEM NO.	PART NO.	DESCRIPTION
101	20110520C12	HEX.SOC.HD.BOLT	302	2152109	O - RING	430	225101	S - RING
102	2111052	SPRING WASHER	303	100130310	END CAP			
103	103910301	DEFLECTOR	304	2303021	AIR PLUG			
104	100110401	SPRING	305	100130401	HANDLE GRIP			
105	100110503	SEAL	401	103943301A01	LOCK HANDLE UNIT			
106	103910604	CAP	402	246142	SPRING PIN			
107	2152011	O - RING	403	106840201	DRIVER GUIDE COVER A			
108	100110906	HD.VALVE PISTON	404	246352	SPRING PIN			
109	2152041	O - RING	405	20110520C12	HEX.SOC.HD.BOLT			
110	2152027	O - RING	406	2111052	SPRING WASHER			
111	100112401	PACKING	407	106840301	DRIVER GUIDE COVER B			
113	100111203	COLLAR	408	106840101A01	DRIVER GUIDE UNIT			
114	2152084	O - RING	409	106840501	PUSHER			
115	2152005	O - RING	410	106840601	SPRING			
116	106810101B01	DRIVER UNIT 500759223	411	106841201	SPRING RETAINER			
117	2152087	O - RING	412	106840801	MOUNTING BRACKET			
118	106810301	CYLINDER	413	20110410C12	HEX.SOC.HD.BOLT			
119	100111701	CYLINDER RING	414	106841301	LATCH PIN			
120	103911902	BUMPER	415	2501042	LOCK NUT			
121	100112301	JOINT GUIDE	416	226105	E - RING			
201	100120103	SEAL	417	103943201	SPRING			
202	100120204	TRIGGER VALVE HEAD	418	106840701	BRACKET			
203	100122001	SPRING	419	2501042	LOCK NUT			
204	100120305	TRIGGER VALVE STEM	420	20110416C12	HEX.SOC.HD.BOLT			
205	2152060	O - RING	421	106841001	PROTECTIVE CASING			
206	2152002	O - RING	422	106840901	SAFETY			
207	100120605	TRIGGER VALVE GUIDE	423	103943201	SPRING			
208	226105	E - RING	424	246192	SPRING PIN			
209	100121501	SAFETY	425	100142801	SAFETY GUIDE			
210	103920801	TRIGGER	426	100741901	SPRING			
211	246142	SPRING PIN	427	100741801	DOOR LATCH			
212	100120903	STEPPED PIN	428	226106	E - RING			
301	100130123	GUN BODY	429	106841401	DOOR LATCH COVER			

BOX - 40/40LW

= 40/40LW